








RUN TIMES

	 GUIDE 10 PLUS	 FLIP 12	 SHERPA 15	 FLIP 24	 FLIP 36	 VENTURE 30	 SHERPA 40	 VENTURE 70	 SHERPA 100PD	 SHERPA 100AC
 HEADLAMP	UP TO 3 RECHARGES	UP TO 3 RECHARGES	UP TO 4 RECHARGES	UP TO 5 RECHARGES	UP TO 7 RECHARGES	UP TO 6 RECHARGES	UP TO 7 RECHARGES	UP TO 13 RECHARGES	UP TO 20 RECHARGES	UP TO 20 RECHARGES
 POV CAMERA	2 RECHARGES	2 RECHARGES	2-3 RECHARGES	3 RECHARGES	5 RECHARGES	5 RECHARGES	6 RECHARGES	10 RECHARGES	18 RECHARGES	18 RECHARGES
 PHONE	1 RECHARGE	1 RECHARGE	1-2 RECHARGES	2 RECHARGES	3 RECHARGES	3 RECHARGES	3-4 RECHARGES	7 RECHARGES	10 RECHARGES	10 RECHARGES
 TABLET	25% BOOST	—	—	—	—	1 RECHARGE	1-2 RECHARGES	2 RECHARGES	3 RECHARGES	3 RECHARGES
 LAPTOP	—	—	—	—	—	—	—	—	2 RECHARGES	2 RECHARGES
 CAMERA	—	—	—	—	—	—	—	—	5 RECHARGES	5 RECHARGES